



UNI

Universal Portable Mod



Instructions Manual

Specification:

Size: 75.3*33.9*25.3mm
Capacity: 650mah
Material: ABS, Zinc alloy, Copper
Atomizer Compatibility:
Resistance >0.5Ω
Diameter 6mm-12mm
Length >42mm

Package Content:

1* UNI battery 1* 510 thread adapter
1* USB cable 1* User manual



How To Use:



1. To connect your atomizer, use the included magnetic 510 thread adapter.

2. Turn on/off battery: Click the power button quickly 5 times in 2 seconds. Lights will flash 3 times.

3. Preheat Mode: Click the power button 2 times. Preheat function will run for 10 seconds with all 3 lights on. When preheat is completed, all 3 lights will flash 8 times and then shut off. To stop preheat, press button another 2 times. Lights will turn off.

4. Adjustable voltage: Low - Middle - High. Low/one light on, Middle/two lights on, High/three lights on.

To change voltage settings click the power button 3 times, continue this to get to desired voltage setting.

5. Height-adjust button: This device is compatible with atomizers with lengths over 42mm. Simply push the height button up or down to adjust the height of your atomizer.

6. Adjustable cartridge holder: This device is compatible with atomizers with a diameter of 6mm-12mm. Simply rotate the diameter adjustment dial to adjust the inner diameter of the UNI to fit the atomizer. Make sure your atomizer is locked in position.

7. Micro USB battery charger included. Battery indicator will glow when it is charging. In around one hour the battery will be fully charged. Once fully charged, the indicator flashes 8 times and then shuts off.

Protection:

Safety cutoff: If the power button is pressed continuously for more than 15 seconds, all 3 lights will flash 8 times before powering off. Release the power button and then press the power to continue vaping.

No Atomizer: Three lights flash 5 times.

Short-circuit: Three lights flash 3 times.

Low battery: Three lights flash 10 times and stops working.

Disclaimers:

People under 21 years of age are not permitted to purchase or use this device. Non-smokers, children, and women breast-feeding should not use this product. The device is not a medical device and is not intended to diagnose, cure or prevent any diseases or other conditions. The manufacturers and sellers will not be responsible for any consequential or incidental damage resulting from the sale or use of any merchandise.

Caution:

1. Please do not over charge, as this will lead to a shorter life of your battery.

2. Do not charge your battery through a car, this can also lead to damage.

3. Please avoid using the device while charging.

4. If the device gets too hot in use, please stop using it for a while.

PATENT NUMBER: 201821255493.3

Original and Exclusive Manufacturer:
Shenzhen Yocan Technology Co., Ltd
www.yocantech.com



Made in China